

# NEC SV8100

## Quick Access Codes

Telco Solutions for  
a Better World

 1300 639 835

***Nextel***  
Enterprise Telephony™

## SV8100 Quick Access Codes ( push speaker or pickup handset )

Change extensions name	: 700 <extension no.><name><hold>
Change system time	: 728 <hh:mm>
Cancel MW (green light)	: 773
Call forward ALL	: 741 <1><destination>
Call forward busy/no ans	: 744 <1><destination>
Do Not Disturb	: 747
Page all handsets	: 701 <1>
Ring volume	: 729 <adjust up/down>
Internal extension ring tone	: 711 <1/2><adjust>
Activate tones while dialling	: 724
Program one touch speed dials on spare buttons on handset	: 751 <button><01><0><number><hold>

For further Nextel created NEC User Guides and Support, go to  
[nextel.com.au/userguides](http://nextel.com.au/userguides)